




Tausch der fest verbauten LED Lichtquelle/Replacement of built in LED light source

Light source/Lichtquelle:
2835-8W-12W-12C2B-F




Step5
Schritt5




Control gear/Treiber:
LWC08W200P

Step2
Schritt2

Step1
Schritt1



Step3
Schritt3



Step4
Schritt4